



42929 - buffer stop for snap holder 20mm high black

Technical drawing



			Nº
black	20mm high	20	42929 ¹⁾

¹⁾ The buffer stop must always be installed. When the buffer stop is used, make sure that the facade has sufficient compression strength (e.g. for thermal insulation).